

How to replace the rear hub bearing on Citroen C3

Carry out replacement in the following order:


1

Place wedge blocks under the front wheels.


2



Loosen the wheel mounting bolts.


3

Raise the rear of the car and secure on supports.

4



Remove the rear wheels.


5


Fully lower the parking brake lever.

6.1




Unscrew the brake caliper fastening

6.2



7



Remove the brake caliper.

8


Remove the brake pads.

AutoDoc recommends:

Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.


Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.

9.1



Unscrew the caliper bracket fastening

9.2




10



Remove the caliper bracket

11.1




Unscrew the brake disc mounting bolts and remove it.

11.2



12




Remove the hub bearing protection cap.

13




Unscrew the wheel hub fastening nut

14



Remove the wheel hub.

15



Install the wheel hub

AutoDoc recommends:


Apply high-temperature lubricant onto the wheel hub bearing fixing bolts.

16




Screw the hub nut.

17




Lock the nut.

18




Install the hub bearing protection cap.

19.1



Install the brake disc and secure it.

19.2




20



Install the brake caliper bracket

21.1



Tighten the brake caliper bracket

21.2




22




Install the brake pads.

23.1




Install the brake caliper and fix it.

23.2



24



Install the wheel.

25



Lower the car and working in a cross order, tighten the wheel bolts.


We hope that this information have been useful for you!



How to replace the rear hub bearing on Citroen C3

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

QUALITY AUTO PARTS



CITROEN



WHEEL/HUB BEARING KITS



CITROEN C3



WHEEL/HUB BEARING KITS FOR CITROEN



WHEEL/HUB BEARING KITS FOR CITROEN C3



AUTODOC IN SOCIAL MEDIA